INTRODUCING The Immovator Drain

PVC

ABS

INSTALLED

Poon Series
PVC

Poon Series
PVC

Poon Series
PVC

Poon Series
PVC

Poon Series
ABS

PVC

Poon Series
ABS

PVC

Poon Series
ABS



Designer White Bathtub Drains!

- Quick, one-person installation; installs in minutes
- Integrated strainer body/drain elbow eliminates one solvent weld joint;
 fewer joints = fewer problems
- Standard high gloss, designer white
- Chrome and 12 other finishes available with QuickTrim® or Universal NuFit®
- Corrosion resistant strainer body, overflow plate and stopper
- Overflow and drain come standard with test membranes; testable up to five floors (22 psi)
- Available in ABS or PVC; Flex Series in PVC only. ABS drain elbow is white
- Removable/replaceable crossbars make drains easy to clean and maintain
- Available with rough-ins and trim (stopper, faceplates) packaged separately
- Five year limited warranty





The Innovator Bathtub Drain Installs In Minutes!

- 1. From inside the tub, insert drain elbow through tub drain.
- 2. Position and align drain elbow. From under the tub, slip on rubber seal, slip washer and nut and tighten to tub.
- 3. Install foam overflow elbow washer up to the flange of the overflow elbow. Push overflow elbow through tub overflow opening.











- 4. From inside the tub, hand tighten the retainer star nut onto the overflow elbow.
- 5. After pressure testing, use knife to cut out test membranes from overflow and drain elbows.
- 6. Snap on overflow plate with overflow slot facing down.
- 7. Tighten the push pull® stopper pin into threaded crossbar. Thread on knob.



12 Additional Finishes Available With QuickTrim® Or Universal NuFit®







Universal NuFit®

For current pricing visit watcomfg.com

For more information contact:

QuickTrim®

Watco Manufacturing Company *Always A Step Ahead*



1220 South Powell Road Independence, MO 64057-2724 tel 816.796.3900 fax 816.796.0875 watcomfg.com