


# Instructions for Sizing/Cutting the <u>Tubular Plastic 550 Series</u> and <u>Tubular Brass 551/552 Series</u>

Always A Step Ahead

PRODUCTS WILL FIT ALL BATH TUBS FROM 13-1/4" TO 22-1/2" DEEP.



- **Step 1:** Measure the depth from the center of the tub overflow hole to the tub drain.
- **Step 2:** <u>Cutting Overflow Tube:</u> From your measurement in Step 1, look at the table below and cut off the amount specified for that length.
- **Step 3:** <u>Selecting Correct Double-Loop Wire:</u> From your measurement in Step 1, look at the table below and select the wire specified for that length.

## **▼ TABLE FOR 550 SERIES TUBULAR PLASTIC**

YOUR MEASUREMENT	TUBE: MARK/CUT ITEM #9	<b>USE WIRE</b>
13 <sup>1</sup> / <sub>4</sub> " to 15 <sup>1</sup> / <sub>2</sub> "	Cut 4" off bottom of #9	B
15 <sup>1</sup> / <sub>4</sub> " to 17 <sup>1</sup> / <sub>2</sub> "	Cut 4" off bottom of #9	C
17 <sup>1</sup> / <sub>4</sub> " to 20"	No Cut	D
20" to 22 <sup>1</sup> / <sub>2</sub> "	No Cut	E

### TABLE FOR 551/552 SERIES TUBULAR BRASS

YOUR MEASUREMENT	TUBE: MARK/CUT ITEM #11	<b>USE WIRE</b>
13 <sup>1</sup> / <sub>4</sub> " to 15 <sup>1</sup> / <sub>2</sub> "	Cut exactly 7" off bottom of #	I1B
15 <sup>1</sup> / <sub>4</sub> " to 17 <sup>1</sup> / <sub>2</sub> "	Cut exactly 5" off bottom of #	11C
17 <sup>1</sup> / <sub>4</sub> " to 20"	Cut exactly 3" off bottom of #	11D
20" to 22 <sup>1</sup> / <sub>2</sub> "	No Cut	E

# 14 16 16 17 18 18 22 11 19 7 20 8 8 21 1 1 19 2 3 3 3 4 9 5 5

551/552 SERIES

For Assistance, call: 800-821-8576 Monday-Friday: 8:00 a.m.-4:30 p.m. CT

Form 550/551. - Rev. 6/09

### **WATCO MANUFACTURING COMPANY**